


1/18

59.0040



095002.010504




FIG. 2A




FIG. 2B




FIG. 2C




FIG. 3


MAIN DISPLAY
410

FIG. 4


PARAMETER
DISPLAY 510

FIG. 5

612 614

CONFIG. DISPLAY 610

620

630

LOGIN PARAMETERS 650

640

Configure a New UCCD or Reconfigure an Existing One

☒ Reconfigure an Existing UCCD ☐ Configure a New Router as a UCCD

New Router Login

Username (if Required) _____

Password _____

Enable Password _____

Router's IP Address _____

Login

Router Configuration Info

Router's New Name

Router's IP Address and Mask **192.168.1.1 w/ 255.255.255.0**

Available Fixed IP addresses **192.168.1.2 thru 192.168.1.50**

DHCP Server Information

Enter the IP address of one or more DNS Servers. If more than one, place a space between IP addresses.

Use Default

Enter the IP address of one or more WINS Servers. If more than one, place a space between IP addresses.

Use Default

Configure Cancel Help

FIG. 6




FIG. 7




FIG. 8

FIG. 7




FIG. 9




FIG. 10

T030T0 2005/250




FIG. 11




FIG. 12





FIG. 13

T05070" 20055260



1110

FIG. 14